


ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.

Name product SHELF CLASS
Article number 4200010, 4200022, 4200023

1

- Ⓐ SHELF PANEL x3
- Ⓑ BOTTOM PANEL x1
- Ⓒ METAL LEG FRAME x2
- Ⓓ FRAME SUPPORT x2



2

- 01 LONG BOLT (M6x40)  x18
- 02 SHORT BOLT (M6x15)  x4
- 03 ALLEN KEY  x1





**Thank you for
purchasing this
Dutchbone product.**

ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.

Name product
Article number

SHELF CLASS
4200010, 4200022, 4200023



**Thank you for
purchasing this
Dutchbone product.**



ASSEMBLY INSTRUCTIONS

Please read the instructions carefully for correct and safe assembly.


Name product
Article number

SHELF CLASS
4200010, 4200022, 4200023


6



7



ADJUST
FEET LEVELER



**Thank you for
purchasing this
Dutchbone product.**

FURNITURE TIPPING RESTRAINT FOR SHELF CLASS

Young children may be injured by tipping furniture and the use of a tipping restraint is highly recommended.

When properly installed, this restraint could provide protection against the unexpected tipping of furniture due to small tremors, bumps or climbing. We recommend mounting this restraint to a wall stud.

WARNING: This product is only a deterrent. It is not a substitute for proper adult supervision.

TIPPING KIT CHECK LIST

CODE	COMPONENT	QTY
01	PLASTIC STRAP	2
02	SCREW	8
03	NYLON WALL PLUG	4
04	PLASTIC BRACKET	4

Installation Instruction:

1. Attach one of the plastic brackets (04) securely near the top back edge of the furniture piece by inserting the screw (02). Refer to picture A.
2. Determine the final position of the furniture piece. Mark location on the wall approximately 2" below the plastic bracket (04) mounted to the back of the furniture.
3. Drill a starter hole into the wall stud. If wall stud is not available, drill a hole into the wall and insert nylon wall plug (03). Gently tap plug until the flange of the plug is flush with the wall.
4. Attach a second plastic bracket (04) by inserting and securing the screw (02) to the wall. Refer to picture B.
5. Align the two plastic brackets (04).
6. Thread the plastic strap (01) through both plastic brackets (04) and tighten until snug.
7. Check to make sure that the plastic brackets (04) are firmly installed the plastic strap (01) is secure.
8. Repeat steps 1-7 at other end of furniture piece.

