
Thank you for purchasing this Desk Table Kaat. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

People to assemble



Tools required



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately 30 MINUTES to assemble with 2 PEOPLE.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE


Fittings and parts checklist

Parts checklist							
Α	Table top assembly x1						
В	Left leg frame x1	C Right leg frame x1					
D	Back rail ×1						
E	Front rail ×1						


Fitting checklist							
F	Bolt ×7 M6x30mm		G	Wood dowel x2 Dia8x30mm			
Н	Cam lock x10		I	Connecting stud x10			
J	Spring washer ×7		K	Flat washer ×7			
L	Allen key #4 x1		М	Felt pad x4			
N	Cam cover sticker x10						

CAM LOCK FITTING GUIDE


1. Remove grub screw.




2. Align the slot of barrel with the hole on side.



3. Fit component.




4. Tighten grub screw.




Step 1

Carefully place the leg frames (part B and part C) onto a soft, flat surface near where the unit will be used as shown below. Screw 10x connecting studs (part I) into the threaded plug using a screwdriver(not included). Then insert 1x wood dowel (part G) into the hole of each leg frame as below shown.




Step 2

With 2 people, carefully place the table top assembly (part A) onto a soft, flat surface near where the unit will be used. Then remove the two drawers as shown below.




Step 3

With 2 people, carefully turn the table top assembly to be as shown below, then open the lids. Insert the cam lock (part H) into the hole inside of back panel making sure the cam lock is positioned in correct direction so that the connecting stud can slide into the cam lock, as shown below.




Step 4

With 2 people, carefully locate the right leg frame (part C) with 1x wood dowel (part G), 1x connecting stud (part I) that already assembled in step 1 as shown below.




Step 5

Secure the right leg frame (part C) as shown below using the bolt (part F) with spring washer (part J), flat washer (part K) and allen key (part L).



Step 6


Turn the cam lock (part H) in a clockwise direction using a screwdriver(not included) as shown below until it is tight fully.




Step 7

With 2 people, carefully turn the table top assembly to be as shown below. Insert the cam lock (part H) into the hole inside of front rail (part E) making sure the cam lock is positioned in correct direction so that the connecting stud can slide into the cam lock, as shown below.

Insert the front rail (part E) over the connecting stud (part I) that already assembled in step 1 as shown below.




Use the allen key (part L) to insert spring washer (part J) and flat washer (part K) with bolt (part F) to secure front rail as shown below.




Step 9

Turn the cam locks (part H) in a clockwise direction using a screwdriver(not included) as shown below until they are tight fully.




Step 10

Insert 2x cam locks (part H) into the holes inside of the back rail (part D) making sure the cam lock is positioned in correct direction so that the connecting stud can slide into the cam lock, as shown below. Insert the back rail (part D) over the connecting stud (part I) that already assembled in step 1 as shown below.




Step 11

Turn the cam locks (part H) in a clockwise direction using a screwdriver(not included) as shown below until they are tight fully.




Step 12

Insert 5x cam locks (part H) into the holes inside of front rail, back rail and back panel making sure the cam lock is positioned in correct direction so that the connecting stud can slide into the cam lock, as shown below.




Step 13

With 2 people, locate the left leg frame (part B) with 1x wood dowel (part G), 5x connecting studs (part I) that already assembled in step 1 as shown below.




Step 14

Secure the left leg frame (part B) as shown below using the bolt (part F) with spring washer (part J), flat washer (part K) and allen key (part L).




Step 15

Turn the cam lock (part H) in a clockwise direction using a screwdriver(not included) as shown below until it is tight fully.




Step 16

Turn the cam locks (part H) in a clockwise direction using a screwdriver(not included) as shown below until they are tight fully.




Step 17

With 2 people, carefully turn the table over as shown below.



Step 18

Carefully align the both side runners of drawer at the same time and slide the whole drawer into the outer runners as shown below.




Step 19

As shown below, attach 10x self-adhesive cam cover stickers (part N) to cover all cam lock (part H) as desired, then with 2 people, carefully place your desk in position.

CAUTION!

Please take care when lifting. Do not drag the table when moving, must be lifted to prevent damaging the les!



Care and Maintenance

Wood furniture

- Wood displays different grain patterns depending on which way they cut for example, the 'medullary rays' which can appear is a mark of good quality timber these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.
- Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.
- All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

- Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.
- Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.
- Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.
- Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Safety instructions

- Never drag furniture when moving it, always lift it.
- Do not sit or stand upon this product.
- · Periodically check all fixings to ensure none have come loose and re-tighten where necessary.
- Please take care when handling or moving the furniture, careless handling may cause damage or injury.
- Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.
- It is recommended that before moving heavy objects to a new location they are completely dis- assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

PLEASE READ!

This veneered product top has a natural open grain finish. Please read the care guide thoroughly. We recommend using mats and wiping up spilled liquids immediately. Avoid placing plant pots or vases with out waterproof mats to prolong the life of this product.

Experiencing problems with your new product?

Before calling customer service, please have your item's batch code ready.

You can find the batch code on the back or bottom of your product as below shown.

(example batch code: 190510)

