



Assembly Instruction

1000187/1000195



Panel No	Panel Sizes	Quantity
1	1500*400*16	1
2	1500*400*16	1
3	268*399*16	2
4	268*360*16	1
5	268*360*16	1
6	1476*278*5	1


Panel No	Panel Sizes	Quantity
7	478*350*16	2
8	469*350*16	1
9	485*261*18	1
10	485*261*18	1
11	485*261*18	1




Fittings



A=16




B=16




C=16




D=16



E=8




F=1




M6*16


G=19




I3=6




H=1




J-1=4



J-2=1



L=12




N=1



Z1=19




Z2=19




U=3


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10







STEP 11




STEP 12




STEP 13




STEP 14



STEP 15




STEP 16



Finish

新-利尼三门电视柜W150邮购包装



Panel No		Panel Sizes	Quantity
12	护角	50*50*50	8
13	泡沫	1500*400*10	2
14	泡沫	440*105*40	2
15	泡沫	1500*105*20	2
16	泡沫	1500*50*20	1
17	泡沫	350*75*15	1
18	泡沫	260*45*15	1
19	泡沫	536*60*15	2
20	泡沫	270*122*15	2
21	泡沫	280*60*35	2
22	泡沫	150*70*35	2
23	纸盒	内径1590*450*115	1